

Product Specification Sheet

Food Service Range

F4

PRODUCT NAME: F4 Descaler

PRODUCT INFORMATION:

F4 Descaler is a concentrated solution that removes lime scale build up and cleans and sanitises commercial dishwashers, glasswashers, bain maries, CIP & tank cleaning.

DIRECTIONS FOR USE:

Recommended on a weekly basis to ensure hygienic and unblocked wash and rinse jets in washers.

1. Drain machine and refill with only fresh water
2. Add 500ml of F4 Descaler to the wash sump
3. Run machine 2-3 times
4. In the case of automatic machines, run consecutive cycles until the machine has washed for 10 minutes.
5. Drain sump, rinse and refill with fresh water
6. NOTE: Descaling solution is corrosive and should be handled wearing gloves and goggles.
For C.I.P. & Tank cleaning use F4 Descaler between 1:40 to 1:80

For the treatment of calcium build up in automatic dishwashing machines.
add 250ml of descaler to machine and run at full cycle.

TECHNICAL DATA:

Please ensure that the correct PPE is used when handling F4 Descaler. Refer to SDS
Suitable for use in kitchens and food preparation areas.
This product is a colourless, syrupy liquid detergent.

Issue date: February 2024

KIS CODE:
KIS-F4

Features:

- * Australian Made
- * Removes lime scale & rust
- * Suitable for food preparation establishments
- * Dilutable
- * Phosphoric Acid
- * Economical
- * PPE Required

PACK SIZE:

5 Litre
15 Litre

CONNECTION
COMPASSION
COMMITMENT
CONSISTENCY